



GLIFE CARE & MAINTENANCE GUIDE

GLIFE FLOOR REQUIRE LITTLE MAINTENANCE TO LOOK AMAZING YEAR AFTER YEAR. CLEANING AND MAINTENANCE FREQUENCY VARIES BASED ON SPECIFIC TRAFFIC VOLUME AND AREA OF USE. WALK-OFF MATS, DAILY SWEEPING AND A REGULAR CLEANING SCHEDULE WILL REDUCE DAILY DIRT, DUST AND BUILD-UP AND MINIMIZE THE NEED FOR MORE EXTENSIVE MAINTENANCE STEPS.

IMMEDIATE CARE AFTER INITIAL INSTALLATION: LVT LOOSE LAY, LVT CLICK & SPC

- + A MINIMUM 1/4" PLYWOOD SHOULD BE USED TO COVER A NEW FLOOR WHEN MOVING HEAVY OBJECTS.
- + **SWEEP, DUST MOP OR VACUUM (WITHOUT A BEATER BAR)** THOROUGHLY.
- + **KEEP THE ROOM TEMPERATURE BETWEEN 65°F AND 85°F.**
- + ONCE THE FLOOR HAS BEEN PROPERLY INSTALLED, YOU CAN BEGIN TO **PERFORM REGULAR MAINTENANCE.**

IMMEDIATE CARE AFTER INITIAL INSTALLATION: LVT DRY BACK

- + ADHESIVE RESIDUE MAY BE REMOVED WITH A CLEAN WHITE CLOTH LIGHTLY DAMPENED WITH MINERAL SPIRITS.
- + A MINIMUM 1/4" PLYWOOD SHOULD BE USED TO COVER A NEW FLOOR WHEN MOVING HEAVY OBJECTS.
- + **DO NOT WET WASH OR SCRUB FLOORS FOR AT LEAST 7 DAYS AFTER INSTALLATION TO ALLOW THE NEW FLOOR TO PROPERLY BOND TO THE SUBSTRATE AND PREVENT ANY MOISTURE INTERFERENCE WITH THE ADHESIVE.** LIGHTLY DAMP MOP IF NEEDED.
- + **SWEEP, DUST MOP, OR VACUUM (WITHOUT A BEATER BAR)** THOROUGHLY.
- + **KEEP THE ROOM TEMPERATURE BETWEEN 65°F AND 85°F.**
- + ONCE THE FLOOR HAS BEEN PROPERLY SET, YOU CAN BEGIN TO **PERFORM REGULAR MAINTENANCE.**

REGULAR MAINTENANCE

- + THESE FLOORS CAN BE EASILY MAINTAINED WITH DAMP MOPPING USING A NEUTRAL VINYL FLOOR CLEANER WHEN NEEDED. THESE PRODUCTS DO NOT REQUIRE WAXING OR POLISHING, BUT MAY BE WAXED OR POLISHED, IF DESIRED.
- + **SWEEP, DUST MOP, OR VACUUM THOROUGHLY TO REMOVE ALL DIRT AND GRIT.**
- + **DAMP MOP WITH A NEUTRAL VINYL FLOOR CLEANER FOLLOWING THE CLEANER PRODUCT INSTRUCTIONS FOR PROPER USAGE AND DILUTION RATE IF REQUIRED.**
- + **RINSE (DO NOT FLOOD) WITH CLEAN WATER.**
- + **ALWAYS REMOVE EXCESS WATER AND ALLOW FLOOR TO FULLY DRY.**
- + **WHEN UTILIZING A LOW RPM MACHINE OR AUTO SCRUBBER, USE**

ADDITIONAL RECOMMENDATIONS

- + **AVOID CLEANERS THAT CONTAIN ABRASIVES OR SOLVENTS, WHICH CAN PERMANENTLY DAMAGE THE FLOOR.**
- + **IF USING WALK-OFF MATS, PLACE WALK-OFF MATS AT ALL ENTRANCES AS WIDE AS THE DOOR AND LONG ENOUGH TO ACCOMMODATE THE SOIL LOAD AND WEATHER CONDITIONS. BE SURE TO USE ONLY NON-STAINING MATS THAT DO NOT FEATURE A LATEX OR RUBBER BACKING AS THESE BACKINGS MAY CAUSE PERMANENT DISCOLORATION TO THE VINYL FLOOR.**
- + **VACUUM ANY MATS OR AREA RUGS REGULARLY.**
- + **USE FLOOR PROTECTORS, MEASURING AT LEAST 1" IN DIAMETER, UNDER FURNITURE TO REDUCE INDENTATION. GENERALLY, THE HEAVIER THE ITEM, THE WIDER THE FLOOR PROTECTOR NEEDS TO BE.**
- + **USE OF BLINDS OR CURTAINS IS RECOMMENDED FOR PEAK SUNLIGHT HOURS TO PREVENT DISCOLORATION OR DAMAGE DUE TO EXCESSIVE TEMPERATURE VARIATIONS.**
- + **ALWAYS USE WET FLOOR SIGNS IN COMMERCIAL APPLICATIONS WHEN PERFORMING ANY WET MAINTENANCE,**

FOR QUESTIONS REGARDING THE MAINTENANCE OF YOUR ALIFE VINYL FLOOR, PLEASE CONTACT US AT INFO@ALIFEFLOOR.COM